

PHF part list		
1	Body	28 Holding Bar
2	Transformer	29 Bronze screw
3	Transformer Back Cov	30 Plastic nut
4	Trans Holding screw	31 Silicone rubber holder
5	Power code	32 Screw
6	Power code holding Cap	33 Pressue spring
7	Heat holder cover	34 Silicone rubber
8	Heat holder	35 Lever
9	Body connect nut	36 Lever bolt
10	Stand pipe	37 Plastic Washer
11	Bottom butterfly nu	38 Plastic bushing
12	Bottom bolt	39 Pressure rubber
13	Pipe connect screw	40 Pressure flat
14	Pedal connect screw	41 Switch pin
15	Pedal	42 Control box cover
16	Bottom Stand	43 Control box
17	Shelf conncet nut	44 Control box body
18	Washer	45 End cap
19	Shelf	46 Micro switch
20	Teflon cloth	47 Plat spring
21	Holding bar cover	48 Rubber cap
22	Adjusting pole	49 M/S nut
23	Pole hanger	50 Micro switch lever
24	Axis	
25	Roll bar cover	
26	Teflon tape	
27	Element wire	

